## AUDI\_V01.10 Daig Function List (Note:For reference only) NOTES: This function is supported. \* This function may be supported, which depends on the actual condition of the vehicle. O This function is not supported. ▲ This function is the new feature in this version. Vehicle Model Year 2011 - 2017 2001 - 2006 1997 - 2017 А3 A4 1998 - 2017 А5 2008 - 2017 A6 1998 - 2017 2011 - 2017 A7 <del>199</del>9 - 2017 A8 2003 -2009 Cabriolet 2012 -2017 Q3 2009 - 2017 Q5 Q7 2007 - 2017 2007 -2017 R8 1999 - 2006 TT Systemlist EcuInfo. ReadCodes EraseCode LiveData 01 Engine Control Module 1 02 Transmission Control Module • 03 Brake Control Module • • 04 Steering Angle Sender • 05 Kessy 06 Seat Adjustment Passenger Side 07 Display Control Unit 08 Air Conditioning • • • • 09 Central Electrics • • • OB Auxiliary Air Heater • • OC Rear Axle Steering 2 OD Sliding Door Left • OE Media Player Position 1 • • • • OF Radio Tuner - Digital 10 Parking Assistance 2 • • • • 11 Engine Control Module 2 12 Clutch Control Unit lacktrianglelacktrianglelacktriangle13 Adaptive Cruise Control 14 Wheel Dampening Electronics 15 Airbag 16 Steering Column Electronics • • 17 Dash Board • 18 Auxiliary Parking Heating 19 Gateway 1B Power-Assisted Steering • • • 1C Vehicle Position Detection 1D Driver Identification • •

lacktriangle

lacktriangle

1E Media Player Position 2

1F Radio Satellite

20 High Beam Assistance				•
21 Battery Energy Control Module 2		•	•	•
22 4WD Electronics		•		
23 Brake Boost		•		
24 Drive Slip Control	•	•		
25 Immobilizer	•	•		
26 Electric Roof Control	•	•		•
27 Display Control Unit Rear		•		
		•		
28 Climate Control Unit Rear	•	•	•	•
29 Light Control Left	•	•	•	•
2B Steer Column Locking		•		•
2D Voice Amplifier	•	•	•	•
2E Media Player Position 3	•	•	•	•
2F TV Tuner - Digital	•	•	•	•
30 Special Function 2	•	•	•	•
31 Engine Electronics Conjunction	•	•	•	•
32 Locking Electroniscs	•	•	•	•
34 Self Adjustment Suspension	•	•	•	•
35 Central Locking Control Module	•	•	•	•
36 Seat Adjustment Driver Side	•	•	•	•
37 Navigation	•	•	•	•
38 Roof Electronics	•	•	•	•
39 Light Control Right	•	•	•	•
3A Special Vehicle Assistant	•	•	•	•
3B Sensor Electronics	•	•	•	•
3C Lane Change Assistance System	•	•	•	•
3D Special Function	•	•	•	•
3E Media Player Position 4	•	•	•	•
40 Air Conditioning Compressor	•	•	•	•
41 Diesel Pump Electronics	•	•	•	•
42 Driver-Door Electronics	•	•	•	•
43 Braker Boost Assistance	•	•	•	•
44 Steering Assistance	•	•	•	•
45 Interior Monitoring	•	•	•	•
46 Central Control Module	•	•	•	•
47 Sound System	•	•	•	•
48 Seat Adjustment Rear Driver Side	•	•	•	•
49 Automatic Lighting Switch	•	•	•	•
4B Multifunction Module	•	•	•	•
4C Tyre Pressure Monitor II	•	•	•	•
4E Control Head Rear Right	•	•	•	•
4F Central Electronics II	•	•	•	•
51 Drive Motor Control Module	•	•	•	•
52 Passenger-Door Electronics	•	•	•	•
53 Parking Brake	•	•	•	•
54 Rear Spoiler	•	•	•	•
55 Headlight Range Control	•	•	•	•
56 Radio	•	•	•	•
57 TV-Tuner	•	•	•	•
58 Auxiliary Fuel Tank	•	•	•	•
59 Towing Protection	•	•	•	•

5B Seat Adjustment Rear Passenger Side	•	•	•	•
5C Lane Keeping Assistance System	•	•	•	•
5D Operation	•	•	•	•
5E Control Head Left Rear	•	•	•	•
5F Information Control Unit 1	•	•	•	•
61 Battery Regulation	•	•	•	•
62 Door Electronics Left Rear	•	•	•	•
63 Entry Assistance Driver Side	•	•	•	•
64 Stabilizers	•	•	•	•
65 Tyre Pressure Monitoring I	•	•	•	•
66 Seat/Mirror Adjustment	•	•	•	•
67 Voice Control	•	•	•	•
68 Wiper Control Unit	•	•	•	•
69 Trailer Function	•	•	•	•
6B Aerodynamics Control Module	•	•	•	•
6C Camera System Rear View	•	•	•	•
6D Electronic Equipment of Trunk Lid	•	•	•	•
6E Display Control Roof	•	•	•	•
6F Central Control Module II	•	•	•	•
71 Battery Charger	•	•	•	•
72 Door Electronics Right Rear	•	•	•	•
73 Entry Assistance Passenger Side	•	•	•	•
74 Vehicle Control System	•	•	•	•
75 Telematics Communication Unit	•	•	•	•
76 Parking Assistance	•	•	•	•
77 Telephone	•	•	•	•
78 Sliding Door	•	•	•	•
7D Auxiliary Heater	•	•	•	•
7E Dash Board Display Unit	•	•	•	•
7F Information Control Unit 2	•	•	•	•
81 Gear Shift Control Module	•	•	•	•
82 Head Up Display	•	•	•	•
84 Night Vision	•	•	•	•
85 On Board-Cammera		•	•	
88 Muiti Contour Seat Driver Side	•	•	•	•
89 Multi Contour Seat Passenger Side	•	•	•	
8A Muiti Contour Seat Rear Driver Side	•	_	•	
8B Adaptive Cruise Control 2		•		
8C Battery Energy Control Module		•	•	
		•	•	
8D Muiti Contour Seat Rear Passenger Side	•	•	•	•
8E Image Processing Electronics	•	•	•	•
8F Pretensioner Front Left	•	•	•	•
90 Pretensioner Front Right	•	•	•	•
91 Engine Control Moudle LT3		•	•	
92 Transmission Electronics LT3	•	•	•	
93 Immobilizer LT3	•	•	•	•
94 Airbag LT3	•	•	•	•
95 Electronic Stability Program LT3	•	•	•	•
96 Instruments Cluster LT3	•	•	•	•
97 Tachograph LT3	•	•	•	•
98 Tire Pressure Monitoring LT3	•	•	•	•

99 Electrical Ignition/Starter Sw	itch LT3				•		
9A Remote Control LT3	T CON LIO			•	•	•	
9B Driver's Door Electronics LT3		•	•	•			
9C A/C Electronics LT3	•	•	•	•			
9D Auxiliary Heater(Fuel)LT3			•	•	•	•	
9E Auxiliary Heater (Electric) LT3		•	•	•			
9F Additional Heater, Water LT3				•	•		
AO Radio 'Audio 5' LT3				•	•		
Al Navigation LT3				•	•		
A2 CD Changer LT3				•	•	•	
A3 Telephone LT3				•	•		
A5 Front Sensors Driver Assistance	o Systom		•	•	•	•	
A6 Microphone Control Unit	е зувтеш			•	•		
A7 Infotainment Interface				•	•		
A9 Actuator for Structure-Borne So	oun d			•	•		
AC Reductant Control Module							
		•	•				
AD Sensors Brake Systems				•	•		
BO Roof Display/Control Head (Roof Control Head) LT3			•	•	•		
B1 Upper Operating Field LT3			•	•	•	•	
B2 Parking Aid LT3			•	•	•	•	
B3 Trailer Function LT3	1 W. 11.	1.00	•	•	•	•	
B4 Vehicle Electrical System Cont		LI3	•	•	•	•	
B5 Programmable Special Module LT3			•	•	•	•	
B6 Steering Column Jacket Switch Module LT3			•	•	•	•	
B7 Access Startsystem Interface			•	•	•	•	
B8 Electronic Roof Control 2			•	•	•	•	
B9 Auxiliary Display Conrol Unit			•	•	•	•	
BA Assembly Mounting	• 1		•	•	•	•	
BB Door Electronics Rear Driver Side			•	•	•	•	
BC Door Electronics Rear Passenger Side			•	•	•	•	
BD High Voltage Battery Charge Management			•	•	•	•	
BE Sliding Door Rear Left			•	•	•	•	
BF Sliding Door Right			•	•	•	•	
CO Actuator For Exterior Noise			•	•	•	•	
C1 Battery regulation LT3			•	•	•	•	
C2 Transmission Control Module 2		•	•	•	•		
C4 DC/DC Converter Control Module			•	•	•	•	
C5 Thermal Management			•	•	•	•	
C6 Battery Charger Control Module			•	•	•	•	
C7 Pedestrian Protection			•	•	•	•	
CB Rear Axle Steering			•	•	•	•	
DO Front Axle Lift System			•	•	•	•	
AUDI_V01.10 Reset Function List (Note:For reference only)							
Vehicle	OIL	EPB	ETC	BMS	SAS	DPF	
AUDI	*	0	0	0	0	0	